


BTE-110 Bluetooth Earbuds Instruction Manual



**** Please read all instructions prior to usink the device.**

Bluetooth power ON/OFF:

1. Power on: Press and hold the multifunctional button for 3 seconds until the LED flashes blue 3 times.
2. Power off: Press and hold the multifunctional button for 3 seconds to power off.
3. If the LED Indicator turns form BLUE to RED when in standby mode, turn the device off to conserve power.
4. Bluetooth pairing:
 - A. Press and hold the multifunctional button for 6 seconds.
The LED Indicator flashes BLUE & RED to indicate pairing mode.
 - B. Activate the Bluetooth function on your mobile device and select BTE-110 to pair. The mobile device indicates if pairing has been successful.

Answering calls:

Press the multifunctional button to answer an incoming call.

Ring off the call:

Press the multi-function button to hang up an active call.

Call back:

Press the multi-function button twice to redial the last caller's number.

Charging:

- Insert the micro-USB plug into the charging port and connect the opposite USB end to a computer or compatible AC wall adapter.
- The LED Indicator lights up RED while charging. The LED turns BLUE when the battery is full.

Volume control:

- Press the "+" button to increase the volume.
- Press "-" button to reduce the volume.

Select previous/next track:

- Press and hold the "+" button to select the previous track-
- - Press and hold the "-" button to select the next track.

ALL RIGHTS RESERVED, COPYRIGHT DENVER ELECTRONICS A/S

DENVER®

www.denver-electronics.com



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen below. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Inter Sales A/S declares that the audio equipment type BTE-110 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: Please enter: www.denver-electronics.com and then click the search ICON on top line of website. Write model number: bte-110

Now enter product page, and red directive is found under downloads/other downloads

DENVER ELECTRONICS A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

www.facebook.com/denverelectronics