

How to charge your DENVER BFH-240

1. Pop out the pedometer itself, just hold the strand and then push the pedometer from top and push it out on the back.



2. Then insert it into the special charger, make sure the contacts are facing towards each other



3. Then insert the USB cable into a pc or a smartphone charger and it will charge the fitnessband.