



BTL-65

Denver.eu 07/2024



FN-1

EN Instruction manual

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference

- 1. This product is not a toy. Keep it out of reach of children. 2. Warning: This product includes lithium polymer batteries. 3. Keep product out of the reach of children and pets to avoid chewing and swallowing.
- 4. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
- 5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel. 6.Do not expose to heat, water, moisture, direct sunlight!
- 7.Please protect your ears against loud volume, Loud volume can damage your ears and risk in hearing loss. 8.Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic
- environment 9. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
- 10. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately. 11. Only charge with supplied USB cable.
- 12.Do not use non original accessories together with the product as this can make the product functionality ahnormal
- 13.Please protect your eyes and do not look directly into the lightning prism when product is operating.

BEFORE THE FIRST USE

- . Please charge the battery for at least 8 hours before your first use of device.
- If the device is not used for a long period of time, the battery may be out of power. Please charge the
- · Connect the supplied USB-cable to the speaker and an external power source. During charging the indicator will

PARTS DESCRIPTION

- Disco light dome
- LED-M kev
- Aux iack
- DC jack On/Off switch

Bluetooth playback

- Turn on the device by using the ON/OFF switch. . Turn on your Bluetooth device, search for the speaker and choose to pair. (If your Bluetooth device ask a
- password, please insert "0000". Once paired successfully, both the speaker and your Bluetooth device will store the device.

Aux playback

- . Connect your external device to the unit by using a standard 3.5mm line-in cable.
- . The connection is made, you can start playback on your external device.

CHARGING

- Charge the battery with the supplied USB cable. You can connect the cable to a computer or USB power supply. The charging indicator LED remains on while the battery is charging
- The device will be fully charged in about four hours.
- When the battery is running low, the device will been. LED function
- Press and hold the LED--M key to turn the Disco light
- Press the LED-M key to switch between different disco light modes

CLEANING AND MAINTENANCE

- . Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the electrical device in water or any other liquid. The device is not dishwasher proof.

ALL RIGHTS RESERVED. COPYRIGHT DENVER A/S



Electric and electronic equipment and included batteries contains materials. components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled

Electric and electronic equipment and hatteries is marked with the crossed out trash can symbol, seen below. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the approriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type BTL-65 is in compliance with Directive 2014/53/EU The full text of the EU declaration of conformity is available at the following internet address: Please enter: Denver eu and then click the search ICON on topline of website. Write modelnumber: BTI -65 Now enter product page, and red directive is found under downloads/other downloads Operating Frequency Range: 2,402-2,480GHz Max Output Power: 2x30W/2x3W RMS

Warning Lithium battery inside DENVER A/S Omega 5A. Soeften DK-8382 Hinnerup Denmark Denver.eu

Contact

Main contact point: contact.hg@denver.eu

Nordics Headquarte Denver A/S Omega 5A, Soefter

Denver Germany GmbH Service Max-Emanuel-Str. 4 94036 Passau

Phone: +45 86 22 61 00

DK-8382 Hinnerup (Push "1" for support)

Denmark

Benelux

For technical questions, please write to support.ha@denver.eu

DENVER BENELUX B.V.

3449 HE Woerden

Phone: 0900-3437623

Spain/Portugal

DENVER SPAIN S.A

Parque Tecnológico

Phone: +34 960 046 883

Phone: +35 1255 240 294

Mail-support.es@denver.eu

E-Mail:denver.service@satfiel.com

Valencia (Spain)

Portugal:

E-Mail:support.nl@denver.eu

The Netherlands

Barwoutswaarder 13C+D

For all other questions please write to: contact homdenver eu

Ronda Augustes y Louis Lumiere, nº 23 - nave

Smartphones & Tablets) Phone: +49 851 379 369 69

(for TV. E-Mobility/Hoverboards/Balanceboards

E-Mail:denver@fairfixx.de

Phone: +49 851 379 369 40

support de@denver eu

Rudolf-Diesel-Str. 3 TOR 2

Fairfixx GmbH

Repair and service

53859 Niederkassel

Austria Lurf Premium Service CmhH Deutschstrasse 1

1230 Wien

Phone: +43 1 904 3085 E-Mail:denven@urfservice.at

LetMeRepair Poland sp. z o.o.

ul. Częstochowska 140 62-800 Kalisz

> Phone: 62 75 38 092 E-Mail:denver-service@letmerepair.c

Godziny pracy: 8 - 18 (poniedziałek - piatek

If your country is not listed above, please write an email to support@denver.eu



Omena 54 Scetten DK-8382 Hinnerup Denmark

denver.eu facebook.com/denver.eu

FN-2 FN-4 FN-5