

## Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Warning: This product includes lithium polymer battery.
3. Keep product out of the reach of children and pets to avoid chewing and swallowing.
4. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
5. Never open the product. Touching the inside electric parts can cause electric shock. Repairs or service should only be performed by qualified personnel.
6. Please remove the Smart watch in case of any leakage or excessive heat from the product to avoid burns or rash.

7. Only charge with the supplied USB cable.
8. Using other accessories than the ones delivered with the product can cause abnormal functionality.
9. Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
10. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.

## **Download App**

Scan the following QR code, download and install the App.



## Scan QR Code and Download

### Pairing

Open the app and set up your profile.

Go to [Device], click [Add a new device]. Choose your device on the scanning list.

You can see the model name "SW-173" on the app after pairing.

### Activate & Charge Device

Make sure power is working normally before initial use. In case the device battery is low, connect the device to the charger. The device will automatically boot up (please connect the magnet USB in normal DC port (5V/500mA) for charging as below.

### Smart Watch Features

Main dials

There are 5 main dials for your option. Long press the touch

ENG

3

panel to choose.



## Physical Exercise



Press and hold the physical exercise page to start a new training measure recording. 10 sports modes are available. The last training data is displayed on the training page.

## Heart Rate Monitor



Touch the heart rate page to start measuring your heart rate.

## Blood Pressure Monitor

ENG

4



Touch the blood pressure page to start measuring your blood pressure.

## SpO2/Blood Oxygen Monitor



Touch the SpO2 page to start measuring your SpO2/blood oxygen.

## State



The smart watch automatically measures steps, calories and distance. The measured data is synchronized to the app.

Note: The sports data stored on the watch is cleared at midnight every day.

## Sleep Monitor



Please note that after you connect the SW-173 with the app, by wearing the smart band during sleep, it will measure your sleep time and quality. The measured data is synchronized to the app and you can

check it on the app.

## Stopwatch




Touch the stopwatch page to start timing, and press it again to stop timing.

## Weather Forecast

The weather page displays the weather information of the current and

next day.



The latest weather information from the App can be synchronized to the

watch if the watch is connected to the App.

## Message Reminder



The watch can synchronize incoming notifications from Twitter, Facebook, WhatsApp, Instagram etc.

The latest 5 messages can be stored on the watch.

Note: You can switch on or off the incoming notification in the app.

## Set



Set up page includes power off, reset, about the device and APP download QR code.

## More Information about Smart watch use in Wet Conditions

The smart watch is water-resistant, which means it is rain-proof and splash-proof and can stand up to even the sweatiest workout.

Note: Do not swim with the smart watch. It is not recommended to shower with the Smart watch, though it does not hurt the band. Remove the watch periodically to

allow your skin to dry and breathe. Whenever you get your bracelet wet, dry it thoroughly before putting it back on.

### **Using the function button and the touch screen**

Press and hold the function button for 3 seconds to turn on the device, press the function button to wake up the device.

### **Quick View**

When the screen is turned off, just turn your wrist towards you and the screen will automatically light up. The watch screen automatically turns off after being idle for a few seconds.

Tap the main dial and slide left, you can find state, heartrate, sleep and physical exercise function quickly.

Warning!

-Lithium battery inside!

-Do not open the product!

-Do not expose to heat, water, moisture or direct

END



Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



[www.denver.eu](http://www.denver.eu)



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

ENG

9

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type SW-173 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [www.denver.eu](http://www.denver.eu) and then click the search ICON on topline of website. Write model number: SW-

173. Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range: 2402-2480 MHZ

Max Output Power: 0 dBm

## **Denver A/S**

Omega 5A, Soeften

DK-8382 Hinnerup Omega 5A, Soeften

**denver.eu**



**facebook.com/denver.eu**