



ECQ-103

denver.eu

Aug 24th 2023



Safety information

1. Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.
2. This product is not a toy. Keep it out of reach of children.
3. Keep product out of the reach of children and pets to avoid chewing and swallowing.
4. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius.
5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
6. Do not expose to heat, water, moisture, direct sunlight!
7. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
8. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
9. Only charge with supplied USB cable.
10. Do not use non original accessories together with the product as this can make the product functionality abnormal.

Warning: Lithium battery inside

Alarm Clock Wireless Charger
Model: ECQ-103

I. Function Buttons



II. Operation manual

1. Power connection

1.1 Connect the USB-A end of the cable to the power adapter and the Type-C end to the product, then the product can operate normally.

2. Wireless charging & USB output

2.1 Wireless charging output power: 10W

2.2 Wireless charging status indicator:

Connected to power: flashes 2x

Standby: off

Charging: on

Fully charged: off

FOD (foreign-object detection): flashing

3. Button functions

3.1 Buttons: "M", "Clock button", "+", "-"

3.2 Time format setting:

Double press the M button to set the 12-hour and 24-hour clocks; PM is displayed in the 12-hour clock.

3.3 Clock time settings:

3.3.1 Press the M button once to set the clock hour, and then press the "+" / "-" key repeatedly to adjust the hour. Hold down the "+" / "-" key to continuously adjust.

3.3.2 After setting the hour, press M to set the clock minute, and press "+" / "-" repeatedly to adjust the minute. Hold down the "+" / "-" key to continuously adjust.

3.3.3 When the setting is complete, press the M button to exit.

3.4 Alarm settings:

3.4.1 Hold down the "+" or "-" key to turn the alarm clock on or off. The alarm indicator will light up after the alarm clock is turned on.

3.4.2 After turning on the alarm clock, hold down the M button to enter the alarm hour setting, and press the "+" / "-" key repeatedly to adjust the hour. Hold down the "+" / "-" key to continuously adjust.

3.4.3 After setting the hour, press M once to enter the alarm minute setting, and press "+" / "-" repeatedly to adjust the minute value. Hold down the "+" / "-" key to continuously adjust.

3.4.4 When the setting is complete, press M to exit.

3.4.5 After the alarm bell rings, do not do anything. After the alarm bell has rung for 3 minutes, the alarm will automatically turn off, or hold down the Clock button to turn off the alarm clock.

3.4.6 When the alarm bell rings, press any button to enter the snooze state. The alarm will ring again after 5 minutes. After 3 minutes, the alarm clock indicator is blinking during the snooze state. In snooze mode, press any button to snooze for an unlimited number of times (if you want to turn off the alarm completely, press and hold the "-" key to turn off the alarm).

3.4.7 The brightness of the clock display can be adjusted in three levels (high, low, off) : Use the "+" and "-" buttons to adjust the brightness of the digital display, and the default setting is the brightest. Each press of "-" reduces the brightness by one level, and each press of "+" increases the brightness by one level. Press the button again to turn off the clock display.

3.5 Power saving function:

3.5.1 Button battery is only used for clock memory function.

3.5.2 When the external power supply is disconnected, all functions are invalid and will return to normal when the power is restored.

4. Precautions:

Special note: If you want to use the alarm clock, wireless charger and USB output at the same time, be sure to use the QC2.0 or QC3.0 power adapter; if you use the 5V voltage supply, the wireless charger and alarm clock can work normally at the same time.

4.1 Do not squeeze or collide.

4.2 Do not disassemble it or put it into fire or water to avoid short circuit leakage.

4.3 Do not use the wireless charger in extremely high temperature, humidity or corrosive environments to avoid damaging the circuit and causing leakage.

4.4 Do not place the magnetic card (ID card, bank card, etc.) with magnetic stripe or chip too close to the unit to avoid magnetic card failure.

4.5 Please keep the distance between the implanted medical device (pacemaker, cochlear implant, etc.) and the wireless charger > 20 cm to avoid potential interference with the medical device.

4.5 Children should be supervised to ensure that they do not play with wireless chargers as toys to

avoid accidents.

4.6 Keep wireless chargers and receiver devices away from water and other liquids.

4.7 If you need to clean the charger, ensure that it is disconnected from the power supply.

4.8 Keep the ambient temperature at 0-45 °C.

4.9 The ambient humidity should be kept at: 20-85% (40 °C).

* The images included in the manual are schematic drawings, and the final product shall be subject to the physical object.

* Includes: charging cable, instruction manual.

* The power adapter is not included. If required, please purchase or use the phone's original power adapter..

III. Specifications

Input: DC 5V/2A, 9V/2A

Output power: 10W

Charging efficiency: 73%

Transmission distance: ≤6mm

Operating frequency: 110-205KHz

Product size: 150*108*70mm

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



www.denver.eu



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately. As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type ECQ-103 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: ECQ-103. Now enter product page, and RED directive is found under downloads/other downloads.

Input: DC 5V/2A, 9V/2A

Output power: 10W

Charging efficiency: 73%

Transmission distance: ≤6mm

Operating frequency: 110-205 kHz

Product size: 150*108*70mm

DENVER A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

www.facebook.com/denver.eu

Contact

Nordics

Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: **+45 86 22 61 00**
(Push "1" for support)

E-Mail
For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux

DENVER BENELUX B.V.
Barwoutswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: **0900-3437623**

E-Mail: **support.nl@denver.eu**

Spain/Portugal

DENVER SPAIN S.A
Ronda Augustes y Louis Lumiere, n° 23 – nave 16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain
Phone: +34 960 046 883
Mail: **support.es@denver.eu**

Portugal:
Phone: **+35 1255 240 294**
E-Mail: **denver.service@satfiel.com**

Germany

Denver Germany GmbH Service
Max-Emanuel-Str. 4
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail
support.de@denver.eu

Fairfixx GmbH
Repair and service
Rudolf-Diesel-Str. 3 TOR 2
53859 Niederkassel

(for TV, E-Mobility/Hoverboards/Balanceboards,
Smartphones & Tablets)

Tel.: +49 851 379 369 69
E-Mail: denver@fairfixx.de

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: **+43 1 904 3085**
E-Mail: **denver@lurfservice.at**

If your country is not listed above,
please write an email to
support@denver.eu



DENVER A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu



Version 1.1